### Build Green

Designing High-Performance Homes

Dan Yaden Western Regional Sales Manager Pactiv Building Products







2100 RiverEdge Parkway, Suite 175 Atlanta, Georgia 30328

Tel 678.589.7300 Fax 678.589.7310



#### Pactiv Building Products has an online AIA course for you!

- · Would you like to learn about protecting your residential walls?
- Would you like to earn an AIA and state credit?

Then go to the AEC Daily website below to take our course titled:

#### Moisture Management in Residential Walls

http://www.aecdaily.com/sponsor/pactiv

This is a free course that is automatically recorded for AIA credit (HSW) upon completion of the online test.

#### A few notes

- If you do not have an AEC Daily account you will need to create a user name and password. This will
  only take a second or two.
- You will need to pull the "password" from one of the slides in the presentation in order to open up the
  test. This password is random and will be in BOLD lettering so just scroll through it and make a note.
- · If you have questions please call your GreenGuard representative.











**Hefty**<sup>®</sup> Consumer Products

#### Food Service / Food Packaging










**Underlayment for Vinyl Siding** 



### Alside Platinum Series









Residential











Commercial


#### **Supporting Products**



**Sill Sealer** 



Building Wrap and Sheathing Tape



**Butyl Flashing** 



Caps





## INTERNATIONAL GREEN CONSTRUCTION CODE™

**PUBLIC VERSION 1.0, MARCH 2010** 

- STANDARD FOR THE DESIGN OF HIGH-PERFORMANCE GREEN BUILDINGS -A JURISDICTIONAL COMPLIANCE OPTION OF THE IGCC
- CICC® 700-2008 NATIONAL GREEN BUILDING STANDARD™ -FOR RESIDENTIAL OCCUPANCIES (by reference)



Building codes are turning green.





"So what's with all these 'green' programs providing 'points' for 'durability' and 'indoor air quality'? I mean it's pretty pathetic if we have to reward architects and engineers when they provide details and specifications that should be basic to fundamental practice. If you design and install a controlled ventilation system that meets Standard 62 you get points. You get more points if you keep the rain out and design the building to dry if it gets wet. And you get still more points if the occupants are actually comfortable. Aren't these code requirements? Shouldn't these be 'the standard of care'?



Joseph Lstiburek, Ph.D., P. Eng.

## Focusing on the Important Stuff Standard of Care for Buildings

- > Structurally sound
- > Controlled ventilation system
- Does not leak rainwater
- ➤ Comfortable
- > <u>Saves energy</u>

"Show me a building that meets code and the standard of care and saves energy and I will show you a green building. A 'real' green building, not a social statement that saps money, time and resources from the real problems facing the planet.

Joseph Lstiburek, Ph.D., P.Eng.

# The Fundamentals of "Green" Buildings

Water-Managed
Energy-Efficient
Sustainable
Resource-Efficient



### Water - Managed

- Durability, Sustainability and Energy Efficiency are functions of moisture control.
- Moisture degradation is the largest factor limiting the service life of a building.
- Rainwater is the largest contributor to moisture accumulation in building enclosures.



### Water Management

2,000 sq ft house "Buffer Capacity"

100-year-old Masonry House (with plaster walls)
500 gallons

#### Green Guard

#### MOLD THRIVES ON THE MOISTURE IN TODAY'S HOUSES

Mold can't survive and reproduce without water, so the ability of particular building restore in to wick away, absorb, and store water (their buffer capacity) is related directly to whether mold can thrive in your losses. Materials with ligher buffer capacities produce fener puddies, making it harder for mold to set up stop.

LET'S COMPARE THE SUFFER CAPACITY OF THREE 2010-SQ.-FT, HOUSES

Most wood-frame houses average 5% recitare content (HQ, Wheel solid is mber reached MC of ground 19%, mold is active. Hithe MC in under 15%, mold in dominant. Mold becomes a problem only when we peak the MC from 5% to above 1.5%. The difference between 5% and 15% in 10%, no the typical mointmentorage capacity of a wood-trained house is prosed 10% by weight. In other worth the house are store. 10% of its weight. in moistane before reald can break out of dome away and

reproduce.

50a

9af


in a typical 20000-eq.-ft. houses, the wood weight. 9000 lb. The Butter capacity is 10% of that, or 900 lb. So the hause can hald \$00 lb. of water before mold. can cause a problem. A guillen of water vrilghail là jatith is a lousy number to divide by so for simplicity let's call it 10 (b. p \$00 lb. claided) by 10 lb. equals 90. gallans. This house žini lave 50 galikasi of basisy plumbing bed flashing, and poor drainage, and mold wan't be a problem.

fromposited shocks and appress of surface of the following for physics of the following for physics of the following for the following for the following fol

in a 100-yearold masonry bourse with plaster wells and a rock foundation, the buffer capacity works out to be about 500 gallone. Wood -Frame House 50 gallons

Steel-Frame House **3 gallons** 

#### Water Management Priority #1: Drain the Rain







Installing Water Resistive Barrier to keep rain off sheathing

### RainDrop provides drainage space







DC14 Drainage Mat

- Gravitational drainage
- Ventilation drying




Water Management, Energy Efficiency and Sustainability are all interconnected.






Leaky houses: stopping air infiltration



1/3 quart of water through diffusion





30 quarts of water through a 1" square hole




Example of diffusion vs. air leakage during one heating season in a cold climate

The <u>Dew Point</u> is the surface temperature at which moisture vapor will condense to liquid water, given a combination of air temperature and relative humidity







The insulation raised the wall temperature thus keeping the inside face of the outside wall above the "dew point".



The Condensation Issue





Mold from condensation on cavity side of exterior sheathing

### GreenGuard Building Wraps





WRB (Water Resistive Barrier) is also air infiltration barrier





Fanfold as WRB when seams taped





Window Unit / Rough Opening Assembly





Air Sealing of rim joist and caulking






Air sealing of mechanicals





Sealed ducts



Thermal Bridging

½-in. drywall

Heat loss viewed through thermal imaging




Siding





Insulation Board breaks thermal bridge







## Resource Efficient GreenGuard Siding Underlayments

- Contain at least 60% post-industrial recycled content
- Reduce energy demand by increasing R-value
- Reduce energy demand by decreasing air infiltration
- > Reduce energy demand by decreasing thermal bridging.





## Resource Efficient GreenGuard Insulation Boards

- Contain at least 30% post-industrial recycled content
- Reduce energy demand by increasing R-value
- Reduce energy demand by decreasing air infiltration
- > Reduce energy demand by decreasing thermal bridging





## Resource Efficient GreenGuard Building Wraps

> Protect sheathing and cavity from rainwater wetting.

➤ Reduce unwanted air infiltration into the wall cavity, thus helping to protect the installed R-value of cavity insulation.



# Green Building Summary Focus on Fundamentals

"Before you can have a 'green' building you need a building first. Presumably this building needs to be able to stand up, not be blown away in a hurricane, not fall down in an earthquake, not burn, not leak rainwater, not be moldy, not rot, not corrode and otherwise be able to meet applicable building codes."

Joseph Lstiburek, Ph.D., P. Eng.

